# Detection of Gas Leakage

#### Ву,

Mahbub-ul-Hasan Nafi 2017000000267

Tilak Chakraborty 2018200000043


Md. Rakibuzzaman 2018000000136

### Resources

- 1. Arduino Uno
- 2. 16X2 (1602) LCD Display
- 3. MQ2 gas sensor
- 4. Active Buzzer

- 5. 10K Potentiometer
- 6. Female header pins
- 7. Breadboard

8. 5V charger or power bank



## Code

```
#include <LiquidCrystal.h>
LiquidCrystal lcd(12, 11, 5, 4, 3, 2);
#define lpg sensor 7
#define buzzer 13
void setup() {
  pinMode(lpg sensor, INPUT);
 pinMode(buzzer, OUTPUT);
  lcd.begin(16, 2);
  lcd.print('LPG Gas Detector');
  delay(2000);
```

## Code

```
void loop() {
  if(digitalRead(lpg sensor)){
    digitalWrite(buzzer, LOW);
    lcd.clear();
    lcd.print('NO LPG GAS');
    lcd.setCursor(0, 1);
    lcd.print('LEAKAGE');
    delay(400);
    digitalWrite(buzzer, LOW);
    delay(500);
```

```
else{
   digitalWrite(buzzer, HIGH);
    lcd.clear();
   lcd.print('LPG Gas Leakage');
   lcd.setCursor(0,1);
   lcd.print('Alert');
   delay(1000);
```